

Your preferred supplier of Laboratory Heat Exchangers. Tubular Heat Exchangers, Plate Heat Exchangers or Scraped Surface Heat Exchangers.

# **Mini Plate UHT/HTST**



Powerpoint International ++81 (0) 48 229 7830

## **Mini Plate UHT/HTST**





プレートUHT	プレートUHTMR# NDARE Lange
1 Raam	1771-1 I IVIR-
the state	N'337'43+-N'87'
10000 1000 1000000	
Langeman Post and	
FT C	Pier HR.6
E I	
Run Down 1979:Feldi 1979:Feldi	1450 rpa 895-815 955
現在値 超速値 0分00秒 0分10秒	▼ 7 89*2 CIP 0(4046): 0FF 73+4

### **Mini Plate UHT/HTST**

No bond Gasketed plate heat exchangers to give a wide variety of heating and cooling duties. The plates are manufactured to our own specification and can be supplied as 1 complete plate pack or individual units for easy maintenance.

·Minimum sample required.

- •Flow rates from 10 to 40 Ltr per hour (Higher available by request).
- Highly accurate electromagnetic flowmeter as option.
- ·Various plate arrangements to allow treatment of difficult products.
- Product system pressures to 10 bar.
- ·Heating to 152 deg C at the flow rates stated.
- •Cooling to below 5 deg C at the flow rates stated.
- ·Holding tubes of any time available and can be placed wherever needed.
- ·Built in refrigerator or your chilled water supply.
- •Built in true CIP (Clean In Place), flow for CIP more than 500 Ltr per hour.
- ·Each heating section is individually controlled to enable a wide setting of product temperatures.
- ·2 Electrically heated hot water recirculators
- •Optional touch panel control fascia with flow path of system.
  - ·No steam required.
  - •SIP (Sterilise In Place) an option for Aseptic sampling.
- ·Aseptic sampling when used with the optional Clean Bench.
- ·In line homogeniser can be added either upstream or downstream.
- ·Level sensor in hopper for easy wash out after product and CIP.
- ·Computer interface with real time temperature recording.

#### Mobile

The machine is completely mobile, can be moved from one location to another very easily and can be positioned in a wet or dry area.

#### Control

Each section is individually controlled and the flow path of the system is shown when the option of the touch panel is taken.

The product is heated by pressurised hot water recirculators which are PID controlled for greater stability and accuracy. The cooling is in 1 or 2 stages dependant on the final cooling temperature required.

#### **Product Pump**

As standard a progressive cavity pump is used. Pump options are available depending on the products to be processed.

#### Service connections

Only mains water and a suitable drain required. Compressed air at 6 bar for the divert valves.

#### Voltages available

200, 220 or 240 volt single phase, 50 or 60 Hz. 200 volt 3 phase, 50 or 60 Hz. 380 volt 3 phase, 50 or 60 Hz. 415 volt 3 phase, 50 or 60 Hz.

#### Amps

Depending on voltage, minimum 20 amps, maximum 45 amps



2-5-10 Hikawacho, Toda-Shi, Saitama-Ken 335-0027, Japan Tel +81 (0) 48 229 7830 Fax +81 (0) 48 229 7831 E-mail : sales@pp2k.net